



1. Start by removing the Rubber seal around the airbox opening. The tube and airbox will need to be removed to do this.



2. The rubber seal has a soft sponge portion on top. Cut down the middle of this part – see next step for what it should look like.



3. Rubber strip with sponge section cut down the middle.



4. Now cut away ONLY one side of the sponge section completely. You should have one side of the sponge section left. See next step for finished part.



5. This photo shows how it should now look. Next step is another angle.



6. Another photo showing the cut section.



7. Refit the seal to the airbox – the UNCUT section should be facing to the outside of the airbox as shown. Make sure the seal pushed into the airbox all the way around.



8. Push the new V2 MAF tube through the opening.



9. Take the MAF boss and 2 Torx Screws.



10. Install the MAF boss to the tube as shown. The screws will cut into the carbon as you tighten them.

**You have now completed the installation of the Eventuri FK8 V2 MAF Tube**

Please take all necessary precautions while installing this system. Eventuri cannot take responsibility for an incorrectly installed intake or any damage caused during installation.