



1. If you have this type of filter housing where there are 6 screws in the front face (with or without a bracket) then you have a Type B Filter. Please follow these steps for removal.



2. If there is a bracket attached – make note of the position of this bracket with respect to the Eventuri Badge. Take a photo for easy reference. You will need to reinstall the bracket in the same position.



3. Remove all 6 screws.



4. Remove the filter and cowl – the cowl could be a flat or curved plate.



5. The old gasket will be on the filter or still on the carbon housing. Remove it.



6. When you are ready to refit the filter, place a new gasket around the filter – line up the holes with the filter holes.



7. Now we will insert the housing over the filter – line up the inserts on the carbon housing with the holes in the filter.

8. Go to the next page



9. Turn over and ensure holes are lined up – if gasket slightly overlaps the inserts on the carbon it is ok.



10. Place the Cowl and bracket back on the filter. Bracket must be IN THE SAME POSITION as it was originally.



11. Now insert and tighten all the screws, use a suitable screw retainer such as Loctite on the screws – do not over tighten.

12. Filter change is now complete.

The recommended cleaning interval for optimum performance is 8000 miles. Filters can be cleaned with compressed air or with a cleaning kit available from your dealer.